Optional Parts

Product Name	Model Name	Split												Split DHW integrated type											
		Super High Power			High Power					R32 Comfort				Super High Power			High Power					R32 Comfort			
		1Ø		3Ø	1Ø		3Ø			1Ø				1Ø		3Ø	1Ø		3Ø			1Ø			
		16	15	17	11	14	11	14	16	5	6	8	10	16	15	17	11	14	11	14	16	5	6	8	10
2nd Circuit Kit	UTW-KZSXE	–	–	–	●	●	●	●	●	●	●	●	●	–	–	–	–	–	–	–	–	–	–	–	–
	UTW-KZDXE	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	●	●	●	●	●	●	●	●	●
	UTW-KZSXJ	●	●	●	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–
	UTW-KZDXJ	–	–	–	–	–	–	–	–	–	–	–	–	●	●	●	–	–	–	–	–	–	–	–	–
Boiler Connection Kit	UTW-KBSXD	–	–	–	●	●	●	●	●	●	●	●	●	–	–	–	–	–	–	–	–	–	–	–	–
	UTW-KBDXD	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	●	●	●	●	●	●	●	●	●
DUO	UTW-KBSXJ	●	●	●	–	–	–	–	–	–	–	–	–	●	●	●	–	–	–	–	–	–	–	–	–
Balancing Vessel	UTW-TEVXA	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
DHW Kit	UTW-KDWXD (External)	●	●	●	●	●	●	●	●	●	●	●	●	–*1	–*1	–*1	–*1	–*1	–*1	–*1	–*1	–*1	–*1	–*1	–*1
DHW Tank 200 Liter 300 Liter	UTW-T20AXH UTW-T30AXH	●	●	●	●	●	●	●	●	●	●	●	●	–*1	–*1	–*1	–*1	–*1	–*1	–*1	–*1	–*1	–*1	–*1	–*1
DHW Tank 200 Liter 300 Liter	UTW-T20BXH UTW-T30BXH	●	●	●	●	●	●	●	●	●	●	●	●	–*1	–*1	–*1	–*1	–*1	–*1	–*1	–*1	–*1	–*1	–*1	–*1
DHW expansion kit	UTW-KDEXE	–	–	–	–	–	–	–	–	–	–	–	–	●	●	●	●	●	●	●	●	–	–	–	–
	UTW-KDEXL	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	●	●	●	●
Circulating Pump	UTW-PHFXG	●	●	●	●	●	●	●	●	–	–	–	–	●	●	●	●	●	●	●	●	–	–	–	–
Swimming Pool Kit	UTW-KSPXD	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Cooling Kit	UTW-KCLXD	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	–	–	–	–
	UTW-KCLXL	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	●	●	●	●
Regulation Extension Kit	UTW-KREXD	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Drain Pan	UTW-KDPXB	–	–	–	–	–	–	–	–	●	●	●	●	–	–	–	–	–	–	–	–	●	●	●	●
Cascade Master Kit (incl. LPB Clip)	UTW-KCMXE	–	–	–	●	●	●	●	●	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–

Product Name	Model Name	Split												Split DHW integrated type											
		Super High Power			High Power					R32 Comfort				Super High Power			High Power					R32 Comfort			
		1Ø		3Ø	1Ø		3Ø			1Ø				1Ø		3Ø	1Ø		3Ø			1Ø			
		16	15	17	11	14	11	14	16	5	6	8	10	16	15	17	11	14	11	14	16	5	6	8	10
Cascade Slave Kit (incl. LPB Clip)	UTW-KCSXE	–	–	–	●	●	●	●	●	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–
HMI Kit	UTW-KHMXE*2	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Remote Controller Wired	UTW-C74TXF*2	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
	UTW-C74HXF*2	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Room Thermostat Wired	UTW-C55XA	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Room Thermostat Wireless	UTW-C58XD	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Outdoor Sensor Transmitter	UTW-MOSXD	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
RF Modules for BSB-Port	UTW-MRCXD	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Web Server	UTW-KW1XD UTW-KW4XD	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
LPB Clip	UTW-KL1XD	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
MODBUS Clip	UTW-KMBXJ	●*5	●*5	●*5	●*5	●*5	●*5	●*5	●*5	●*5	●*5	●*5	●*5	●*5	●*5	●*5	●*5	●*5	●*5	●*5	●*5	●*5	●*5	●*5	●*5
Service Tool (incl. OCI700 Adapter)	UTW-KSTXD	●*3	●*3	●*3	●*3	●*3	●*3	●*3	●*3	●*3	●*3	●*3	●*3	●*3	●*3	●*3	●*3	●*3	●*3	●*3	●*3	●*3	●*3	●*3	●*3
Service Tool Software	UTW-KPSXD	●*4	●*4	●*4	●*4	●*4	●*4	●*4	●*4	●*4	●*4	●*4	●*4	●*4	●*4	●*4	●*4	●*4	●*4	●*4	●*4	●*4	●*4	●*4	●*4
External Connect Kit	UTY-XWZXZ2	–	–	–	●	●	●	●	●	–	–	–	–	–	–	–	●	●	●	●	●	–	–	–	–
	UTY-XWZXZ3	●	●	●	–	–	–	–	–	–	–	–	–	●	●	●	–	–	–	–	–	–	–	–	–
Electrical back-up heater relay	UTW-KBHXL	–	–	–	–	–	–	–	–	●	●	●	●	–	–	–	–	–	–	–	–	●	●	●	●

● : Available – : Not Available

*1: DHW operation is possible without DHW Kit and DHW Tank.
*2: 19 Languages included, no separate Eastern European RC necessary. C74TXF: Built in Room Temperature sensor C74HXF: Built in Room temperature and Humidity sensor
*3: UTW-KL1XD is required for the connection.
*4: UTW-KW1XD or UTW-KW4XD is required for the connection.
*5: Additional optional parts necessary.